

MAINTENANCE

Cleaning and disinfecting on a regular basis is important for maintaining the performance of your humidifier.

IMPORTANT: Water left in the tank or base when not in use may result in buildup of mineral deposits and bacteria which may inhibit the output efficiency as well as void the warranty. If water remains in the Water Tank for more than a day or two, bacterial growth is possible.

DAILY MAINTENANCE

1. Turn off, unplug from outlet and empty water from tank & base daily.
2. Allow tank & base to air dry.
3. Leave mist cover off the tank until ready for next use.

WEEKLY MAINTENANCE

1. Turn off, unplug from outlet and empty water from tank & base.
2. Fill the water tank halfway warm water and add 2 Tablespoons of white vinegar. Let sit for 30 minutes. Empty tank and rinse with plain water.
3. Remove the mist chamber from the underside of the Mist Cover and rinse with Warm soapy water.
TIP: Clean the nebulizer with a damp cloth or cotton swab after soaking.
4. Allow tank & base to air dry and leave mist cover off the tank until the next use.

NEVER IMMERSE HUMIDIFIER BASE IN WATER.

END-OF-SEASON MAINTENANCE & STORING YOUR HUMIDIFIER

1. Turn off, unplug from outlet, and empty water from tank.
2. Follow instructions for weekly maintenance above.
3. Let all parts dry completely.
4. Store humidifier in a cool, dry place.